

Accessory installation is the responsibility of the customer.  
Motorcycle Adventure Products and Hepco & Becker accept no  
responsibility for matters arising from the use of these recommendations.



*English Translation*

Web Site: [www.hepco-becker.de](http://www.hepco-becker.de)

**HB-650.4502**

Gepäckbrücke / Rear Carrier

**YAMAHA TDM 900**

***"Please read in conjunction with the  
factory instructions & illustrations  
supplied!"***

**NB1:**

**Please read in conjunction with the factory illustrations  
supplied with the original (German) instructions!**

**NB2: If you feel that you do not have the necessary skills or  
tools to fit this kit we recommend you consult your local dealer!  
If you are unsure, please contact us!**

**NB3: When fitting any spacers always measure them and  
ensure you are using the right one in the right location!**

**NB4: Where original screws are removed and thread lock  
compounds were used in their location, we recommend that  
you consider use of similar compounds when refitting.**

---

*The kit covers the following parts:*

- 1 rear carrier
- 1 retaining adaptor ( Reft )
- 1 retaining adaptor ( Right )
- 2 truss head screws M8 x 60
- 2 truss head screws M6 x 20
- 2 washers  $\varnothing$  8.4 mm
- 2 washers  $\varnothing$  6.4 mm
- 2 self-locking nuts M6
- 2 aluminum distances  $\varnothing$  18 x  $\varnothing$  9 x 10 mm

***Assembling instructions***

The rear turn signals remain in the original position.

Hepco & Becker are distributed in Australia & New Zealand by Motorcycle  
Adventure Products

For more information of this or any other product please contact on:

LANDLINE: +61 7 3139 0387 or

E-MAIL: [info@motorcycleadventure.com.au](mailto:info@motorcycleadventure.com.au)

**Accessory installation is the responsibility of the customer.  
Motorcycle Adventure Products and Hepco & Becker accept no  
responsibility for matters arising from the use of these recommendations.**

***Preparing work:***

Remove the seat and then dismantle the tail fairing as well as the original retainers. In addition the carrier part, which is installed on the framework with four screws, must be resolved.

Now dismantle the luggage hooks, which are bolted in the back in the framework, they are no longer required. In their place the retaining adapters provided are installed, using the original screws

(See image)

Now re-install the tail fairing using the original retainers again.

(See images)

***Attachment of the Rear Rack***

***Front:*** Into the front screw connections of the original retainer, insert the aluminum spacers  $\varnothing 18 \times \varnothing 9 \times 10$  mm and bolt (the rear rack) over it the (original) luggage carrier with the truss head screws M 8 x 60 together with washers.

***Rear:*** The tubing (support) struts of the rear carrier are screwed onto the outside of the (installed before) retaining adapters with the truss head screws M 6 x 20, together with washers and self-locking nuts.

***Check all screw connections after the assembly for tightness!***

***Please consider our attached service information esp. pannier load carrying etc.***

As the further accessories for the TDM, we offer:

650.4502 0001 pannier frame kit black

501.415 0001 engine motor guard black

***\*\*\* This is a machine translation; no guarantee is made of its accuracy.***

**Hepco & Becker are distributed in Australia & New Zealand by Motorcycle  
Adventure Products**

**For more information of this or any other product please contact on:**

**LANDLINE: +61 7 3139 0387 or**

**E-MAIL: [info@motorcycleadventure.com.au](mailto:info@motorcycleadventure.com.au)**