

Accessory installation is the responsibility of the customer.  
Motorcycle Adventure Products and Hepco & Becker accept no  
responsibility for matters arising from the use of these recommendations.



*English Translation*

Web Site: [www.hepco-becker.de](http://www.hepco-becker.de)

**HB-650.637.0001/9**  
**Pannier Frames**  
**BMW R 1200 GS**

**NB1:**

**Please read in conjunction with the factory illustrations  
supplied with the original (German) instructions !**

**NB2:**

**If you feel that you do not have the necessary skills or tools to  
fit this kit we recommend you consult your local dealer!  
If you are unsure on any matter, please contact us!**

**The kit covers the following parts:**

1 luggage carrier (left)	24 washersø6.4 mm
1 luggage carrier (right)	4 washersø8.4 mm
1 reinforcement prop	2 alu spacers ø18 x Ø7 x 30 mm
12 truss head screws M 6 x 50	2 alu spacers Ø18 x Ø9 x 12 mm
2 truss head screws M 8 x 20	2 clamping jaws with thread plate Ø18mm
4 truss head screws M 6 x 16	2 clamping jaws with thread plate Ø 25 mm
12 self-locking nuts M 6	2 self-locking nuts M 8

**ASSEMBLY INSTRUCTIONS**

The rear turn signals remain in the original position.

**Attachment lower front, on the left and right side (A)**

Install the clamping jaws Ø 18 mm on the rear prop of the pillion  
footrest arms. (Please also read the separate assembly instruction for  
the clamping jaws!).

Hepco & Becker are distributed in Australia & New Zealand by Motorcycle  
Adventure Products

For more information of this or any other product please contact on:

LANDLINE: +61 7 3139 0387 or

E-MAIL: [info@motorcycleadventure.com.au](mailto:info@motorcycleadventure.com.au)

**Accessory installation is the responsibility of the customer.  
Motorcycle Adventure Products and Hepco & Becker accept no  
responsibility for matters arising from the use of these recommendations.**

**Attachment upper front, on the left and right side (B)**

Install the clamping jaws  $\varnothing$  25 mm at the frame. (Please also read the separate assembly instruction for the clamping jaws!).

**Attachment rear upper, on the left and right front screw connection (C)**

Add the aluminum spacers  $\varnothing$  18 x  $\varnothing$  7 x 30 mm as spacers between the pannier frame and bike frame. Use the truss head screws M 6 x 50 together with washers for this screw connection.

**Rear screw connection (D)**

Add the aluminum spacers  $\varnothing$  18 x  $\varnothing$  7 x 12 mm as spacers between the pannier frame and bike frame. Use the socket-head cap screws M 6 x 50 together with u-disk for the screw connection.

**Attachment of the reinforcement prop (E)**

This runs underneath the number plate support. The attachment to the luggage carrier takes place with truss head screws M 8 x 20 together with washers and self-locking nuts M 8. In the kit also are supplied truss head screws M 6 x 16 together with washers and self-locking nuts are intended for the attachment of the luggage lock adapters! (The adaptors come with the pannier cases).

**Check all screw connections after the assembly for tightness!**

**Please read and consider our attached service information**

\*\*\* This is a machine translation, no guarantee is made of its accuracy.

**Hepco & Becker are distributed in Australia & New Zealand by Motorcycle  
Adventure Products**

**For more information of this or any other product please contact on:**

**LANDLINE: +61 7 3139 0387 or**

**E-MAIL: [info@motorcycleadventure.com.au](mailto:info@motorcycleadventure.com.au)**