

Accessory installation is the responsibility of the customer.
Motorcycle Adventure Products and Hepco & Becker accept no
responsibility for matters arising from the use of these recommendations.



English Translation

Web Site: www.hepco-becker.de

HB-650.648

Gepäckbrücke / rear carrier

BMW R1200R

***"Please read in conjunction with the
factory instructions & illustrations
supplied!"***

NB1:

**Please read in conjunction with the factory illustrations
supplied with the original (German) instructions!**

**NB2: If you feel that you do not have the necessary skills or
tools to fit this kit we recommend you consult your local dealer!
If you are unsure, please contact us!**

**NB3: When fitting any spacers always measure them and
ensure you are using the right one in the right location!**

**NB4: Where original screws are removed and thread lock
compounds were used in their location, we recommend that
you consider use of similar compounds when refitting.**

1.

Assembling instructions

The rear turn signals remain in the original position.

Preparing work:

Take the plastic covers laterally from the fairing tail (side)
Using the drilling template cut out and present / attach to the covers,
mark & drill $\varnothing 17$ mm.

2.

Replace the drilled plastic covers on both sides.

Hepco & Becker are distributed in Australia & New Zealand by Motorcycle
Adventure Products

For more information of this or any other product please contact on:

LANDLINE: +61 7 3139 0387 or

E-MAIL: info@motorcycleadventure.com.au

**Accessory installation is the responsibility of the customer.
Motorcycle Adventure Products and Hepco & Becker accept no
responsibility for matters arising from the use of these recommendations.**

3.

Attachment of the retaining prop:

This is installed inside in the fender. Dismantle the two original screws \varnothing 5 mm. The latches of the retaining prop are bolted up under the fender using the socket-head cap screws M 5 x 20 together with washers \varnothing 5.4. adding in each case 2 washers \varnothing 6.4 as intermediate spacers

4.

Attachment of the rear carrier above:

Put in each case by the appropriate drillings of the plastic covers an aluminum spacer \varnothing for 15 x \varnothing 9 x 25 mm. Over it the support arms of the rear carrier are placed. The screw connection takes place with the socket head screws M 6 x 40 together with washers \varnothing 6,4.

The kit parts list has English descriptions and drawing as per ea step!:

Check all screw connections after the assembly for tightness!

Please consider our attached service information esp. pannier load carrying etc.

*** This is a machine translation; no guarantee is made of its accuracy.

**Hepco & Becker are distributed in Australia & New Zealand by Motorcycle
Adventure Products**

For more information of this or any other product please contact on:

LANDLINE: +61 7 3139 0387 or

E-MAIL: info@motorcycleadventure.com.au