

Accessory installation is the responsibility of the customer.
Motorcycle Adventure Products and Hepco & Becker accept no
responsibility for matters arising from the use of these recommendations.



English Translation

Web Site: www.hepco-becker.de

HB-700.922

Micro Flocator Lights

for **502.922 Tank Guard**

BMW R 1200 GS

*"Please read in conjunction with the
factory instructions & illustrations
supplied!"*

Additional Instructions – AUS

- 1. If you feel that you do not have the necessary skills or tools to fit this kit we recommend that you use your local dealer or an automotive electrician!
*If you are unsure, please contact us!***
- 2. The German kit states to connect the sense wire to the blue grey wire in the OEM (park), to comply with most AUS state laws, this should connect to the white high beam wire.**
- 3. Ensure that any single insulated cable is wrapped in good quality black electrical tap (or you can use heat shrink) and laid to ensure that there is no possibility of chafing or pinching on the frame!**
- 4. Allow wiring should be rechecked on completion before inserting fuse.**
- 5. Test lamp operation (operates with high beam) and then align beams accordingly.**

Hepco & Becker are distributed in Australia & New Zealand by Motorcycle
Adventure Products

For more information of this or any other product please contact on:

LANDLINE: +61 7 3139 0387 or

E-MAIL: info@motorcycleadventure.com.au

**Accessory installation is the responsibility of the customer.
Motorcycle Adventure Products and Hepco & Becker accept no
responsibility for matters arising from the use of these recommendations.**

Links hinten (E) Left back	⑦	1	Motorschutzbügel links
Originalschraube entfällt Original screw is void (torx)	⑨	1	Inbusschraube M 12 x 80 Socket-head cap screw
	①①	1	U-Scheibe Ø 12,5 mm Washer
	①②	1	Aludistanz Ø25xØ13x25 mm Aluminium spacer
Links vorne (F) Left front	⑧	1	Inbusschraube M 10 x 55 Socket-head cap screw
	①①	1	U-Scheibe Ø 10,5 mm Washer
	①③	1	Aludistanz Ø25xØ11x30 mm Aluminium spacer
Befestigungsbügel at attachment handles	⑥	1	Gewindestift M 6 x 10 mm Grubscrew

AUS NOTES:

We suggest the following ...

- 1. When removing, if the rear Torx screw is tight that you take the bike for a short ride & warm the engine & retry. NB The torx screw is replaced by Socket head in the kit!**
- 2. Use the correct part as listed above in specified location on the drawing.**
- 3. Assemble all parts to finger tight to get correct alignment.**
- 4. Tighten lower bolts to engine frame, then top bolts to frame (under tank) then finally the grub screws.**

Nach der Montage alle Verschraubungen auf festen Sitz kontrollieren!
Check all screw connections after the assembly for tightness!

Bitte beachten Sie unsere beigefügten Serviceinformationen.
Please read and consider our attached service information

Als weiteres Zubehör lieferbar: As to other accessories available:

**Tankschutzbügel Tank protection guard
Art.-Nr. 502.922 00 01 schwarz und 502.922 00 09 silber**

**„Micro-Flooter“ (Zusatzscheinwerfer) Art.-Nr. 700.922.
(Auxiliary headlight)**

*** This is a machine translation, no guarantee is made of its accuracy.

**Hepco & Becker are distributed in Australia & New Zealand by Motorcycle
Adventure Products**

For more information of this or any other product please contact on:

LANDLINE: +61 7 3139 0387 or

E-MAIL: info@motorcycleadventure.com.au